

Pallmann Magic Oil Floor Care Guidelines



General Cleaning


Pallmann® Hardwood Floor Cleaner: Cleaning frequency will be dependent on the floor's location, level of use and degree of dirt retention. General cleaning should consist of sweeping with a soft broom or dry dust mop, vacuuming and/or misting the floor with Pallmann Hardwood Floor Cleaner and cleaning with a dampened microfiber mop.

Directions For Use:

- 1. Vacuum or sweep floor before cleaning to remove dirt, grit and dust.
- 2. Spray or mist a 4'x6' area of your floor (use full strength from the bottle). You may also spray your mop cover with the cleaner or lightly dampen the mop cover with clean water. Wetting helps loosen dirt on the floor surface and quickens the cleaning process.
- 3. To clean, simply move the mop back and forth. Rinse the mop in clean water as it gets soiled during cleaning. A soiled mop will only move dirt around the floor instead of removing it. Thoroughly wring out mop after each rinsing. For stubborn spots, sticky spills and shoe marks, spray cleaner directly on the soiled area and wipe with a clean cloth or mop pad by hand if necessary.

See Magic Oil Floor Care chart on reverse for service level & frequency schedule

Long-Term Maintenance



Directions For Use:



- 2. Shake well before using. It is recommended to ventilate the work area during application.
- 3. Dilute 1oz Pallmann Magic Oil Care in 20oz of water in a spray bottle. Spray mist the floor to achieve an even layer of Magic Oil Care over an area that can be mopped in a few seconds. Using a dampened microfiber mop, spread the misted area, working with the grain of the wood, and allow to dry. Continue the procedure until the entire floor is uniformly covered. Be careful not to leave heavy lap lines or pooling. NOTE: Magic Oil Care may be applied undiluted in heavy traffic areas or on floors that sustain heavy commercial wear.
- Clean tools after use with water.
 Disposal: In accordance with local, state and/or national regulations.
 See Magic Oil Floor Care chart on reverse for service level & frequency schedule









Special Maintenance

Pallmann® Clean & Pallmann® Magic Oil 2K: Pallmann Clean is formulated to remove Pallmann Magic Oil Care and thoroughly clean the floor prior to re-applying Magic Oil 2K. IMPORTANT: Floors MUST be re-coated with Magic Oil 2K after using Pallmann Clean to maintain proper floor protection. Do not use Pallmann Clean for General Cleaning. Use only Pallmann Hardwood Floor Cleaner.

Directions For Use:

- 1. Vacuum and clean the floor using Pallmann Hardwood Floor Cleaner (see General Cleaning above).
- 2. Shake well before using. Pallmann Clean should be applied at room temperature.
- 3. Residential & General Office Applications: Mix Pallmann Clean in a spray bottle at a 10:1 dilution (10 parts water to 1 part Clean). Heavy Commercial Applications: Use undiluted in a spray bottle.
- 4. Spray Pallmann Clean on a small section of floor and allow it to 'work' for no more than 5 minutes. Buff with a green scrub pad on a rotary buffer.
- 5. After buffing, immediately wipe the surface with clean water using dampened towels, rinsing towels frequently. Clean small sections of the floor at a time to prevent the Pallmann Clean from drying before wiping is complete.
- Clean up with water.

Disposal: In accordance with local, state and/or national regulations.

See Magic Oil Floor Care chart below for service level & frequency schedule



Service Level & Frequency Schedule

Service Level	Product	Frequency
General Cleaning	Pallmann Hardwood Floor Cleaner	Daily/Weekly depending on floor location and level of use
Long-Term Maintenance	Pallmann Magic Oil Care	Level of Use – Light: Apply approx. every 6 months if needed depending on surface appearance Medium: Apply approx. every 1-2 months if needed depending on surface appearance Heavy: Apply once or twice a month if needed depending on surface appearance
Special Maintenance	Pallmann Clean Pallmann Magic Oil 2K	Level of Use – Light: Apply approx. every 2-3 years or when needed depending on surface appearance Medium: Apply approx. every 1-2 years or when needed depending on surface appearance Heavy: Apply approx. every 6 months to 1 year or when needed depending on surface appearance

